

..... 1

..... 1

Gantry

× Gantry

- Gantry Command Position, Feedback Position
- 가 1000 100
1100 , 1000 .

- Position Monitor “C.Position.PreCorrection”, “F.Position.PreCorrection”
 - “C.Position.PreCorrection” Command Position
 - “F.Position.PreCorrection” Feedback Position
 - Position Count “C.Count.PreCorrection”, “F.Count.PreCorrection”

Position Monitor

Reset	C.Position	F.Position	F.Speed	Torque
Axis 0	200 000		0	- 8.70
Axis 1	200 000		0	8.90
Axis 2	0		- 2	0.00

- ▼ C.Position
- ▼ F.Position
- ▼ C.Count
- ▼ F.Count
- ▼ C.Speed
- ▼ F.Speed
- ▼ Torque
- C.Position.Motor
- F.Position.Motor
- C.Position.PreCorrection
- F.Position.PreCorrection
- C.Count.Motor
- F.Count.Motor
- C.Count.PreCorrection
- F.Count.PreCorrection

- 가 () .

Reset	C.Position	F.Position	C.Speed	F.Speed	Torque	C.Pos.Pre Corr	F.Pos.PreC orr
Axis 0	100 000	100 000	0	- 7	- 8.30	100 000	100 000
Axis 1	100 000	100 000	0	0	3.20	99 900	99 900
Axis 2	0	- 2	0	2	0.00	0	- 2

From:
<http://comizoa.com/info/> - -

Permanent link:
http://comizoa.com/info/doku.php?id=application:comiide:tool:gantry:gantry_apply_check&rev=1559007266

Last update: **2024/07/08 18:23**