

- History ..... 1
- 1.11.3.0 ..... 1
- Adds ..... 1
- Changes ..... 1
- Debugs ..... 1
- 1.11.2.0 ..... 1
- 1.11.1.0 ..... 2
- 1.11.0.0 ..... 3
- 1.10.6.0 ..... 3
- 1.10.5.0 ..... 4
- 1.10.4.0 ..... 4
- 1.10.3.0 ..... 4
- 1.10.2.0 ..... 4
- 1.10.1.0 ..... 5
- 1.10.0.0 ..... 5
- 1.9.3.9 ..... 5
- 1.9.3.8 ..... 6
- 1.9.3.7 ..... 6
- 1.9.3.5 ..... 6
- 1.9.3.4 ..... 6
- 1.9.3.3 ..... 6
- 1.9.3.2 ..... 7
- 1.9.3.1 ..... 7
- 1.9.3.0 ..... 7
- 1.9.2.1 ..... 7
- 1.9.2.0 ..... 8
- 1.9.1.0 ..... 8
- 1.9.0.0 ..... 9
- 1.8.2.0 ..... 9
- 1.8.1.1 ..... 9
- 1.8.1.0 ..... 9
- 1.8.0.0 ..... 10
- 1.7.0.1 ..... 10
- 1.7.0.0 ..... 10

# History

## 1.11.3.0

### Adds

- DevList.Search Module 가
- SearchTextBox "Search" 가
- FormAIStatusCode : , Code가 0
- SdoAbortCodeDescription 가 : Shell LogViewer 가
- FormSetup.Form.AiPrecision Property 가
- Shell.Check 가
- ELMO Slot Driver
- FormFirmware.Reset MultiSelect
- NetState EscState
- Config.CheckMultiAxis

### Changes

- DcOffsetDefault
- 5001 Profile Step ID PhysAddr + 1 ( : ID = PhysAddr)

### Debugs

- Disconnect Topology Update Topology
- DevList.Search :
- NetID 0 FormESC
- FormSlot Module ModIndent가 0 가
- NetState

## 1.11.2.0

- 
- ControlLock 가
- AppSetup.t.formInfo.AlarmMonitor.DisplayAlarm Property 가
- Config.InPdoSkipCount Property 가
- AllowNodeNameChange Property 가<sup>1)</sup>
- DeviceList.xml 가
- Config.DriverRawPDO
- AIState , Stop
- FormFirmware.Reset Device
- RemoteMode
- 
- FormAI / FormAO Graph 가

- Dictionary enum
- TempController 0
- FormSetup 가
- Config
  - , 가
  - NetInfo.LogicIn / NetInfo.LogicOut Servo 가
  - Scan / Download Exception
  - IO Scan/Download 1 Dock
  - Download BackupFile Exception
- Shell
- Master-Slave
- GetModulInfos Exception 2)

### 1.11.1.0

- App
- Dock Expert
- 5001 Profile IO
- FormDevList
  - ExpandOne, ExpandAll, CollapseOne, CollapseAll 가
  - SearchNodeWithChannelName 가
  - DeviceName 가
- MotorMonitor : ColumnCount Property 가
- FormDIO
  - RootColumnCount Prop가erty 가 : DIO Form ColumnCount
  - ColumnCount\_1 Enum 가
- FormAI / FormAO : Precision
- Setup
  - AppSetup.Form.DeviceList.InitTreeLevel Property 가
  - AutoLoa .NameOnly Property 가
- Config
  - TopologyView : Port line
  - Module Append
  - DefaultZoom
  - ProfileNo 3)
  - UpdateForm : Event
  - ID / ID , TreeView
  - MultiAxis ID 가4)
  - TopologyView AIState 5)
  - DI / DO StartCh 가
  - SM / FMMU 6)
  - DioMap, AioMap Leak
  - IsRevisionNoNotMatchAnError Property가 false , RevisionNoNotMatch
  - Net , TopologyView Update
  - CustomIoMap : Map 가
  - MDP type Object-DataType Matching 7)
    - Object DataType Size가 , Object DataSize

- InfoRefFilePath Node
- ServoTunes
  - ServoTunes
  - LoadOne
- AlarmMonitor 가 : Axis Alarm, Slave CommError
- EtherCAT
  - MailBox Abort <sup>8)</sup> AbortCode log 가
  - Device가 ID가 0 가 AlarmMonitor
  - AlarmState Property 가 : AIState가 AlarmState AlarmMonitor

### 1.11.0.0

- SlaveCfg : ProfileNo 가
- 402 Profile Address
  - 402 Profile 64 .
  - , INVALID\_ADDRESS\_IN\_402 ConfigError
- ConfigError 가 ( )
- formConfig Leak
- ProfileNo.5003
- ServoTunes Data Read Error
- UsingStationAddress Property 가
  - CSA
- FormConfig.TopologyView
  - AIStatus 가
  - Group AIStatus
- Config.BaseAIState Property 가
- DcOffsetDefaultValue 가
- Firmware Reset : Main → Firmware

### 1.10.6.0

- EtherCAT
  - **DLL Logger** **AppDown**
  - Dictionary Search 가
  - DataType Object bit 가 가
  - TempController 가
  - Scan ecCfg\_SetSlaveConfig : PreOP
  - ESI SM Enable Enable
- cEIP
  - cEIP AppDown
  - cEIP Version Parsing
  - cEIP MotorState Update failed

- NEMO
  - FW, Lib Version read failed

### 1.10.5.0

- SoftEtherCAT 가
  - ESC, SlaveRW
- EtherCAT Config
  - FMMU Section : Servo Sect
  - EBus\_2 + Mii\_2 Type Matching
  - ProcessData Entry Type ETC 가
- DO Repeat RepeatCount 가 0 ,

### 1.10.4.0

- IO Form Dock 가
- Setup : FormIO HideMenu Property 가

### 1.10.3.0

- Config
  - TopologyView : PortMonitoring Option 가
  - NetInfo : DcOffset : %
- Dictionary : Enum
- <sup>9)</sup> 가
- EtherCAT : OPMODE\_PT 가

### 1.10.2.0

- FormConfig : Slave AutoReset 가
- FormPDO : 2 ~ 7 bit size Data 가



### 1.9.3.8

- EtherCAT Lib

### 1.9.3.7

- Shell
  - API ,
- EtherCAT
  - Firmware Upload UI
  - ETS-MC02P, CMC HomeReturn

### 1.9.3.5

- DeviceList
  - EtherCAT (Driver) : MajorNo.MinorNo.BuildNo.RevNo

### 1.9.3.4

- DeviceList
  - EtherCAT : MajorNo.MinorNo.BuildNo.RevNo
  - EtherCAT Version Compare

### 1.9.3.3

- HomeReturn
  - HomeReturn , MotorMonitor / AxisList

### 1.9.3.2

- ServoTunes
  - Nikki Denso : Nikki Denso 가 , Exception Error
  - Servo가 Net ServoTunes

### 1.9.3.1

- EtherCAT InitAlState DontChange , PDO
- Slave SDO Read
- ServoTunes EEPROM Write 가

### 1.9.3.0

- EtherCAT Version : File → GetVerInfo
- AutoSaveEnable, AutoSavePath 가
- AutoLoadEnable, AutoLoadPath 가
- FirmUp : 0 State가
- DO Custom Channel Control : Setup
- LX554 48 : LX554 → LX554(48)
- LX553 : LX553 → LX552(40)

### 1.9.2.1

- EtherCAT HomeReturn Success
- UnknownESC Register Read (DIStatus )
  - TopologyView, ESC Viewer Update
  - 1.9.2.0 YASKAWA Driver Topology가

### 1.9.2.0

- ESC Viewer
  - PortControl 가
  - UI
  - ESC Type Register Read/Wrtie
- TopologyView
  - ESC Redundancy Check
  - Port Open ESC
- DSP Viewer
  - FW 2.66 EEclnfoID 가 (SendCount, ReceiveCount )
  - Read Checkbox 가
- DeviceList
  - EtherCAT VersionCheck

### 1.9.1.0

- ServoTunes
  - UI
  - Write One-All, Write All-All
- Config
  - TopologyView
  - SlaveTree
    - Coupler - Coupler / Hub - Hub
  - PortOpen
  - SlaveInfo DcInfo 가
  - OHT\_Step 가
  - 402 Profile Axis Info Update
  - Scan
  - Master Redundancy
- FormIO
  - EtherCAT IO Form Title NetID 가
  - EtherCAT AI / AO Aio Mode
  - DIO GetMulti Selction 가 (GetMulti / GetOne)
    - LX534 + 64 IO , SDK 32
- DeviceList
  - EtherCAT Slot 10 , Sorting
    - 1,10,11,2,3,4 1,2,3,4,10,11
- Dictionary

- , UI
- Shell
  - ToHex(),ToDec(),ToBit() 가
- FirmUp
  - DeviceNode DeviceInfo Update

### 1.9.0.0

- Config DC-Sync Factor (OP )

### 1.8.2.0

- Dictionary : EnumType null
  -
- AI / AO Form : Multi-Channel Name Copy/Paste
- SevoTunes : SanyoDenki, NikkiDenso

### 1.8.1.1

- SlaveRW : SDO Read Sign/UnSign
- DevList Form : PulseType
- Config : 402Profile DcSyncMode가 가

### 1.8.1.0

- CMC Axis 가
- EtherCAT FW Version 1.60 DCSyncEnable

### 1.8.0.0

- EtherCAT DcSyncEnable 1, 2 가
- Dictionary : EnumType Text
- SDP Type Visible 가
- 가 Log Skip
- ServoTunes : Yaskawa EtherCAT

### 1.7.0.1

- Setup Form MinorBugFix
- Setup Form NEMO ELP Logic

### 1.7.0.0

- EtherCAT ReserseConnetionCheck MinorBugFix
- EtherCAT Multi-Device FirmwareUpdate
- EtherCAT Virtual Module Append MinorBugFix

1)

false DevList Node 가

2)

Invisible Node 가

3)

가 900

4)

ID ID

5)

AIState 가

6)

Config SetFMMU() , Scan Get

7)

Dictionary WeiduMuiller Object가

8)

CoeSDO Read Fail / write Fail

9) 10)

,

PlatformInfo.xml, DeviceList.xml

From:

<http://comizoa.com/info/> - -

Permanent link:

[http://comizoa.com/info/doku.php?id=application:comiide:20\\_intro:10\\_history&rev=1713945338](http://comizoa.com/info/doku.php?id=application:comiide:20_intro:10_history&rev=1713945338)

Last update: **2024/07/08 18:23**