

**NEMO Master Board** ..... 1  
**NEMO Master Board** ..... 1  
..... 2  
..... 3

# NEMO


× NEMO

## NEMO Master Board

### NEMO Master Board


(NemoFWU.exe)

- 1. - Firmware - NemoFWU.exe
- 2. RT(LX520), ML2(LX530S), ML3(LX530), SS3(LX540/H)





- 가 DLL

- Firmware DLL .




- Browse .dat





- Start



From:  
<http://comizoa.com/info/> - -

Permanent link:  
[http://comizoa.com/info/doku.php?id=faq:comiapp:fwupdater:01\\_nemo&rev=1625622850](http://comizoa.com/info/doku.php?id=faq:comiapp:fwupdater:01_nemo&rev=1625622850)

Last update: **2024/07/08 18:22**