

NEMO Master Board 1
..... 2
..... 3


NEMO

× NEMO

NEMO Master Board


(NemoFWU.exe)

- 1. - Firmware - NemoFWU.exe
- 2. RT(LX520), ML2(LX530S), ML3(LX530), SS3(LX540/H)





- 가 DLL

- Firmware DLL




- Browse .dat





- Start



From:
<http://comizoa.com/info/> - -

Permanent link:
http://comizoa.com/info/doku.php?id=faq:comiapp:fwupdater:01_nemo&rev=1626249214

Last update: **2024/07/08 18:22**