

cEIP 1

 가 1

 1

 2

 Hardware 2

 Software 2

 3

ceNetConfig.ini 3

 3

 3

 4

 가 **(Win 10)** 4

 가 **(Win 7)** 4

 가 5

 Windows 5

 5

 MADIC 6


 6

cEIP

× cEIP

cEIP

가



- 1.
- 2. IP, SE

- 1. (Hardware)
- 2. .()
- 3. ceNetConfig.ini .
- 4. 가 .
- 5. .
- 6. .

Hardware

- Master IP Slave ID
- Master MSB,LSB
- Slave 가





Software

- IP Address

(IP : 192.168.1.00, : 255.255.255.0, : 192.168.1.254)

- IP 192.168.1.1~192.168.1.254 IP



	Name		Description
	P	Power led	모듈에 전원이 입력되면 점등됩니다.
	A	Active led	모듈이 정상동작 할 경우 점등됩니다.
	E	Error led	모듈에 에러가 발생시 점등됩니다.

- ceNM-IP(SE)

LED가

- P 가 P A가

ceNetConfig.ini


- 64bit : C:\Windows\SysWOW64\ceNetConfig.ini
- 32bit : C:\Windows\System32\ceNetConfig.ini

- - - 192.168.1. - [] - [] -

ceNetConfig.ini

- cEIP
- LAN 가 1 IP


가 (Win 10)



- Windows 10

[Windows] – [] – []

가 (Win 7)



- Windows 7

[Windows] – [] – []


가


Windows

- -
- -
- C6711powerflasher.exe
- Cesdkdaemon.exe
- COMIZOA Ethernet/IP Windows x86 BasedService

Coprocess

MADIC





From:
<http://comizoa.com/info/> - -

Permanent link:
http://comizoa.com/info/doku.php?id=faq:comiapp:fwupdater:02_ceip&rev=1625625040

Last update: **2024/07/08 18:22**