

C-NET Setup 1
 Contents 1
1. PC 1
2. cnD00-32 DC 24V 가 1
3. C-NET Download 2
4. 2
5. comilDE 3

C-NET Setup

× C-NET

C-NET Setup

Contents


- 1. PC COMI-LX412a/b
- 2. cnD00-32 DC 24V 가
- 3. C-NET Download
- 4.
- 5. comiIDE

1. PC

- PC가 COMI-LX412a/b
- cnD00-32 COMI-LX412a/b RJ-45


2. cnD00-32 DC 24V 가

- DC Power Supply cnD00-32 DC 24V 가
- 24V가 (DC24V , 24V) GND가 (DC 24V , 0V)가
- 가

	Pin #	Description
	1	External power DC +24 (P24 IN)
	2	External power DC Ground (N24 IN)

3. C-NET Download

- comizoa.info download C-NET



- Package Download

C-Net


Package	Example	Manual	Certificate	ETC	History
v1.1.0.0					
v1.0.0.0					

Download (Package) Download (Core)

4.


- COMI-LX412a/b 가

COMI-LX412a/b C-Net Digital I/O Board가




5. comiIDE

- comiIDE



- Scan CNet



From:
<http://comizoa.com/info/> - -

Permanent link:
http://comizoa.com/info/doku.php?id=faq:downloadandsetup:c-net:00_c-net_setup&rev=1625648241

Last update: **2024/07/08 18:22**