

1. Comizoa Serial Daemon	1
2. Setup	1
가	1
EtherCAT Master Configuration	2
Serial Daemon Licence Key	2
3.	2
COM Port	2
Serial Channel	3
.....	5
Mapping	6
Mapping	6
Mapping	7
Serial	9

Comizoa Serial Daemon


× Comizoa Serial Daemon
× Serial Daemon

Comizoa EtherCAT

가

가

1. Comizoa Serial Daemon



- Serial Daemon

1) PDO, SDO

가

Windows

가

2.

Setup

가

- 가
 - 가
 - temp
- - - .zip


EtherCAT Master Configuration

- PCI

Serial Daemon Licence Key

- Serial Daemon
Comizoa
가
• Serial Daemon

3.







• 가


COM Port


Serial Channel







- ComboBox Mapping . ECAT Serial Slave COM Port
 - Serial Channel {idx:{ } [{
 - }] 1 0









Mapping



•


Mapping**Mapping**


Mapping



- **Mapping** **Remove**

Mapping





- Mapping
- Mapping
- Info.INI
- - **Auto Save**




Info.ini



LXUARTCON.dll



Serial_Daemon.exe



• Info.ini


Mapping

가

Mapping

가

Serial



- Serial Daemon Mapping
Slave 가 가 .

Windows Serial

EtherCAT

1)

ETS-SC08A

From:
<http://comizoa.com/info/> - -

Permanent link:
http://comizoa.com/info/doku.php?id=faq:downloadandsetup:serialdaemon:00_setup&rev=1677739196

Last update: 2024/07/08 18:22