



EtherCAT				cELP	DAQ				NEMO	
ECS	ETS	EPS	EVS		CP	SD	LX	DX		
COMI-LX550, COMI-LX551, COMI-LX552, COMI-LX554				ceMC02P, ceMC04P					COMI-LX502L, COMI-LX504L, COMI-LX508L, COMI-LX504EX, COMI-LX508EX, COMI-LX534L	COMI-LX520, COMI-LX530, COMI-LX540, COMI-LX540H
				ceNM-SE, ceNM-PE, ceNM-IP, ceNM-RT, ceNM-ML2, ceNM-ML3, ceNM-SS						
					COMI-CP101	COMI-SD101, COMI-SD103, COMI-SD104	COMI-LX101, COMI-LX102	COMI-DX101		
ECS-DI16N, ECS-DI16P	ETS-DI16N, ETS-DI16P, ETS-DI32N-E, ETS-DI32N-T	EPS-DI24N	EVS-DI32N	ceDI32N, ceDI32P		COMI-SD403				
ECS-DO16P, ECS-DO16N, ECS-DO04R	ETS-DO16N, ETS-DO16P, ETS-DO04R, ETS-DO32N-E, ETS-DO32N-T	EPS-DO24N	EVS-DO32N	ceDO32N, ceDO32P		COMI-SD402				
/	ETS-D08MN, ETS-D08MP			ceD16CM	COMI-CP401	COMI-404, COMI-SD414, COMI-SD424F, COMI-SD434, COMI-SD434EX				
ECS-AI08V, ECS-AI08I, ECS-AI04T, ECS-AI04R, ECS-AI04IH, ECS-AI04VH	ETS-AI08H-E	EPS-AI08H, EPS-AI04RNT		ceAI04R, ceAI08A, ceAI04H, ceAI04RTD, ceAI04TC	COMI-CP201	COMI-SD201, COMI-SD202, COMI-SD203	COMI-LX201, COMI-LX202, COMI-LX203	COMI-DX201		
ECS-AO02IH, ECS-AO04IH, ECS-AO04VH	ETS-AO04I-E, ETS-AO04V-E	EPS-AO04I		ceAO02A, ceAO04V, ceAO04I	COMI-CP301, COMI-CP302	COMI-SD301		COMI-DX301		
/	ETS-A0402MV-E									
/	ECS-NC100	ETS-HUB	EPS-Interface, EPS-CPL00A							
ECS-SC02I232, ECS-SC02I485	ETS-SC08A			ceSC04A, ceSC04I-232, ceSC04I-485		COMI-SD624/628/634/638/644/648(EX o)	COMILX624/628/634/638/644/648(EX o)			
	ETS-EC04H-M		EVS-RPM	ceCN08A						
				ceCM01A					COMI-TM402, COMI-TM403, COMI-TM404, COMI-TM532, COMI-TM534	

From:

<http://comizoa.com/info/> - -

Permanent link:

[http://comizoa.com/info/doku.php?id=faq:unused:00\\_products&rev=1629350417](http://comizoa.com/info/doku.php?id=faq:unused:00_products&rev=1629350417)

Last update: **2024/07/08 18:22**