

Configurator

,
..... 1
..... 1

Configurator

x Configurator

Configurator

- Slave
- Slave Topology Map
- Slave Address, SyncMode
- Slave InPDO Map, OutPDO Map
- Master



ComilDE

Main tab

Config



From:

<http://comizoa.com/info/> - -

Permanent link:

http://comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:10_configurator&rev=1541985593

Last update: **2024/07/08 18:22**