

|              |   |
|--------------|---|
| Configurator | 1 |
|              | 1 |

# Configurator

× Configurator

## Configurator

- Slave
- Slave Topology Map
- Slave Address, SyncMode
- Slave InPDO Map, OutPDO Map
- Master



ComilDE

### Main tab

## Config



From:

<http://comizoa.com/info/> - -

Permanent link:

[http://comizoa.com/info/doku.php?id=platform:ethercat:1\\_setup:10\\_config:10\\_configurator&rev=1576117845](http://comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:10_configurator&rev=1576117845)

Last update: **2024/07/08 18:22**