


Slave Info	1
.....	1
Address Setup	2
Property	3
FMMU / SM	4

Slave Info

- Configurator Slave Information Tab
- Address, SyncMode, DeviceType



- SlaveInfo
- ESI Slave
- Address
- SyncMode

Property FMMU / SM



Product	ETS-A0402MV-E	ProductCode	0x5032D406
Vendor	COMIZOA	VendorID	0xAAAAAAA
Group	ETS	RevisionNo	0x16102400

Address

AddressMode A	ALIAS
Alias	580
AliasLLMode B	IdentificationADO
AutoAddress	-6
PhysAddr_Hex C	0244

Info

PhysicsType	YY
SyncMode D	FreeRUN

Support

IsAoE	False
IsCoE	True
IsFoE	True
IsMbx	True

Type

DeviceType_401 E	AI, AO
ProfileNo	401
SubProfileNo	12

AddressMode

Apply All **3**

1 - Info

- Slave Type

2 - Property

- Slave
- (default) ESI
- 가

3 - Apply All

- , Type Slave
- VendorID ProductCode 가 Type

Address Setup

A - AddressMode

- ALIAS : Master가 Slave Address
 - Slave
 - 가 OP Mode 가
- CSA : ALIAS Slave

B - AliasILMode

- IdentificationADO : Slave ESC Memory
- IdentificationReg134 : Slave
 - MicroController ID Switch가

C - PhysAddr_Hex

- 16 Address
- 402 Profile(Driver) IO **BaseAddress**

× Address가 Download Slave

Property

D - SyncMode

- xml xml mode
- xml 가 , , FreeRUN

E - DeviceType_401

- DeviceType 401

Property FMMU / SM



Product
Vendor
Group

ETS-A0402MV-E
COMIZOA
ETS

ProductCode
VendorID
RevisionNo

0x5032D406
0xAAAAAAA
0x16102400

**Address**

AddressMode	ALIAS
Alias	580
AliasLMode	IdentificationADO
AutoAddress	-6
PhysAddr_Hex	0244

Info

PhysicsType	YY
SyncMode	FreeRUN

Support

IsAoE	False
IsCoE	True
IsFoE	True
IsMbx	True

Type

DeviceType_401

ProfileNo

SubProfileNo

AI, AO

- NONE
- DI
- DO
- AI
- AO
- DIInfo

DeviceType_401

 Apply All

- DeviceType ,
- “DI Info” Type , DI
 - DO DeviceID PDO

FMMU / SM

FMMU

- Slave **FMMU**

SM

- Slave SyncManager

From: <http://comizoa.com/info/> --

Permanent link:
http://comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:20_desc:30_slaveinfo&rev=1592285920

Last update: **2024/07/08 18:22**