

Config 1

Config

Configurator Configuration

Guide

- [Configurator](#)
- [Configuration](#)

Description

- [Project](#)
 - Slave List
- [Setup : Configuration Option](#)
- [TopologyView](#)
 - Topology, AIStatus, AIStatus Error ,
 - Port , **InPort - OutPort** , DC Delay
- [Net Info](#)
 - Cycle Time, Process Time, Logic Memory
 - DI, DO, AI, AO Channel Map
- [Slave Info](#)
 - Address, SyncMode, DeviceType
- [Process Data](#)
- [Slot Info](#)
- [Addressing](#)
 - IO Module Channel Mapping
 - Auto Addressing
- [Distibuted Clock Delay](#)
- [Reverse Connected Slave](#)
- [Module Change](#)

Trouble Shooting

- [SafeOP](#)
-
- [Unknown Slave 가](#)
- 가

From:

<http://comizoa.com/info/> - -

Permanent link:

http://comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:start&rev=1586842393

Last update: **2024/07/08 18:22**