

# Table of Contents

Config .....	1
Guide .....	1
Description .....	1
Trouble Shooting .....	2

## Config

Configurator 및 Configuration 에 대한 안내 페이지입니다.

### Guide

- **Configurator**
- **Configuration**

### Description

- **Project 관리**
  - Slave List 비교
- **Setup : Configuration Option 설정**
- **TopologyView**
  - Topology, AIStatus, AIStatus Error 확인,
  - Port 상태, **InPort - OutPort** 오삽입, DC Delay 확인
- **Net Info**
  - Cycle Time, Process Time, Logic Memory 확인
  - DI, DO, AI, AO Channel Map
- **Slave Info**
  - Address, SyncMode, DeviceType 변경
- **Process Data**
- **Slot Info**
- **Addressing**
  - IO Module에 대한 Channel Mapping 방식 설정
  - Auto Addressing
- **Distibuted Clock Delay 측정**
- **Reverse Connected Slave**
- **Module Change**

## Trouble Shooting

- **Scan Error**
- **Master Device 초기화 실패**
- 주소 확인 실패
- **Master-DC 확인 실패**
- **OP 전환 실패**

From:

<http://comizoa.com/info/> - -

Permanent link:

[http://comizoa.com/info/doku.php?id=platform:ethercat:1\\_setup:10\\_config:start&rev=1586855742](http://comizoa.com/info/doku.php?id=platform:ethercat:1_setup:10_config:start&rev=1586855742)

Last update: **2024/07/08 18:22**