


State Machine ..... 1

# EtherCAT State Machine

× EtherCAT State Machine



- BootStrap :
  - FoE<sup>1)</sup>
  - Init<sup>2)</sup>
- Init :
- Pre-OP : MailBox
- Safe-OP : MailBox, TX PDO, Slave, Status, Data
- OP : MailBox, TX PDO, RX PDO, Slave, Status, Data

<sup>1)</sup>

File access over EtherCAT

<sup>2)</sup>

Init → Bootstrap or BootStrap → Init

From:  
<http://comizoa.com/info/> - -

Permanent link:  
[http://comizoa.com/info/doku.php?id=platform:ethercat:2\\_info:10\\_alstatus&rev=1586243209](http://comizoa.com/info/doku.php?id=platform:ethercat:2_info:10_alstatus&rev=1586243209)

Last update: **2024/07/08 18:22**