


State Machine 1

EtherCAT State Machine

x EtherCAT State Machine



- BootStrap :
 - FoE¹⁾ MailBox 가
 - Init ²⁾
- Init :
 - 가
- Pre-OP : MailBox 가
 -
- Safe-OP : MailBox , TX PDO 가
 - Slave Status Data
- OP : MailBox , TX PDO, RX PDO 가
 - 가
 - 가 가

¹⁾ File access over EtherCAT

²⁾ Init → Bootstrap or BootStrap → Init

From:

<http://comizoa.com/info/> - -

Permanent link:

http://comizoa.com/info/doku.php?id=platform:ethercat:2_info:10_alstatus&rev=1586243209

Last update: **2024/07/08 18:22**