

MLink3

HomeSetSpeedPattern

x LX530 HomeSetSpeedPattern

GetParam

- cmcHomeSetSpeedPattern , PhaseID , 0~2 가
- SW

- PhaseID :

```
0 :
1 :
2 :
```


* ComilDE HomeSetSpeedPattern , PhaseID 0,1,2

Command	Info
HomeSetSpeedPattern	IdenAcId = 8, phaseID = 8, speedMode = 2, workSpeed = 18000, accel = 18000, decel = 180000
HomeSetSpeedPattern	IdenAcId = 8, phaseID = 1, speedMode = 2, workSpeed = 2800, accel = 2800, decel = 28000
HomeSetSpeedPattern	IdenAcId = 8, phaseID = 2, speedMode = 2, workSpeed = 2800, accel = 2800, decel = 28000

RTEX, MLink3 SetParam, GetParam

x LX520, LX530 SetParam, GetParam

- GnSetParam, GnGetParam ,
- _____



From:

<http://comizoa.com/info/> - -

Permanent link:

<http://comizoa.com/info/doku.php?id=faq:errata:01&rev=1662450840>

Last update: **2024/07/08 18:22**